

ADDONICS TECHNOLOGIES

Model: AESDD12U2



Hardware Installation

Plug and Play for Windows 2000, XP and Vista

1. Plug in the USB connector of the Mini Digidrive II to a USB port.
2. Windows will detect a new hardware and will install all required driver for the Mini Digidrive II.
3. Go to My Computer and you should see four new unique drive letter icons.

Flash Memory Cards:

MS, MS Duo, MS Pro, MMC, SD, Mini SD, SM

1. Insert card with metal contact strip facing down (up for SM) and the cut out notch on the left side (right side for SM) going toward the Mini Digidrive II.

Compact Flash (CF) or Micro drive

1. Insert card with edge, with the holes facing toward the Mini Digidrive II. Making sure to line the card up with rails.
2. Push gently all the way in.
3. To remove the card, merely pull the card back out.

Windows 98 Driver and Utility Installation


1. Turn on your computer.
2. Insert the I/O Driver CD into the CD-ROM drive of your computer.
3. Double-click Browse CD button > DigiDrives > Driver Download > Mini DigiDrive II for Win98. Extract the File
4. Double-Click "SETUP.EXE" and follow the instructions on your computer screen to install the drivers for your Mini Digidrive II.
5. Restart your computer when prompted.
6. Open "My Computer" to view icons of media cards that are inserted in the Mini Digidrive II. Read and write to these media using the same method.

TECHNICAL SUPPORT (8:30 am to 6:00 pm PST)

Phone: 408 453-6212
Email: <http://www.addonics.com/support/query/>

ADDONICS TECHNOLOGIES

Model: AESDDHU2 & AESDD12U2WP



Note: Model AESDD12U2WP is Write Protected.

Hardware Installation

Plug and Play for Windows 2000, XP and Vista

1. Plug in the USB connector of the 12-in-1Mini Digidrive to a USB port.
2. Windows will detect a new hardware and will install all required driver for the 12-in-1Mini Digidrive.
3. Go to My Computer and you should see four new unique drive letter icons.

Flash Memory Cards:

MS, MS Duo, MS Pro, MMC, SD, Mini SD, SM

1. Insert card with metal contact strip facing down (up for SM) and the cut out notch on the left side (right side for SM) going toward the 12-in-1Mini Digidrive.

Compact Flash (CF) or Micro drive

1. Insert card with edge, with the holes facing toward the 12-in-1Mini Digidrive II. Making sure to line the card up with rails.
2. Push gently all the way in.
3. To remove the card, merely pull the card back out.

Windows 98 Driver and Utility Installation

1. Turn on your computer.
2. Insert the I/O Driver CD into the CD-ROM drive of your computer.
3. Double-click Browse CD button > DigiDrives > Driver Download > Mini DigiDrive II for Win98. Extract the File
4. Double-Click "SETUP.EXE" and follow the instructions on your computer screen to install the drivers for your 12-in-1Mini Digidrive.
5. Restart your computer when prompted.
6. Open "My Computer" to view icons of media cards that are inserted in the 12-in-1Mini Digidrive. Read and write to these media using the same method.

TECHNICAL SUPPORT (8:30 am to 6:00 pm PST)

Phone: 408 453-6212
Email: <http://www.addonics.com/support/query/>